OPERATION INSTRUCTION – WS9123

A. Features
1. Weather forecast clock
2. 12/24Hr selectable
3. Month, date and day display
4. Alarm function, 5 minute snooze function
5. Calendar range:2003~2052, default 2003
6. °C/°F selectable
7. Temperature range: 0°C~50°C(32°F~122°F)
8. Humidity range: 20~90%RH
9. Max/Min indoor temperature/humidity record

B. Operate Instruction
1. Function keys: MODE, SET, C/F, ADJUST, MAX/MIN, SNOOZE
2. At time display mode, press "C/F" key to switch °C/°F
3. At time display mode, press "MAX/MIN" key to view the max/min value of temperature / humidity, hold "MAX/MIN" key 2 second to clear record.
4. Press "MODE" to switch among the status of Time, Alarm and Calendar.
5. Time setting:
    1). At the normal time display status, hold "SET" key 2 seconds to, 12/24hr will flash, then press "ADJUST" key to switch 12/24Hr.
    2). Press "SET" key again, hour will flash, then press "ADJUST" key to set hour, hold "ADJUST" key to enter speedy adjusting mode.
    3). Press "SET" key again, minute will flash, then press "ADJUST" key to set minute, hold "ADJUST" key to enter speedy adjusting mode.
    4). Press "MODE" key to confirm the setting, or no operation in the 2 minutes that follows, the previous setting will be confirmed automatically, and then enter into time display status.
6. Alarm setting:
    1). At alarm mode, hold "SET" key 2 second, hour will flash, then press "ADJUST" key to set hour, hold "ADJUST" key to enter speedy adjusting mode.
    2). Press "SET" key again, minute will flash, then press "ADJUST" key to set minute, hold "ADJUST" key to enter speedy adjusting mode.
    3). Press "MODE" key to confirm the setting, then press "ADJUST" key to turn on alarm
    4). Press "MODE" key again to turn off alarm and integral point reminder function.
    5). Press "MODE" key again to turn on alarm, then press "ADJUST" key to turn off alarm and integral point reminder function.
    6). If alarm is on, when the alarm is ringing, press "SNOOZE" button once, the alarm will ring again after 5 minutes. Or press any other key to exit.
7. Calendar setting:
    1). At calendar mode, hold "SET" key 2 second, year will flash, then press "ADJUST" key to set year, hold "ADJUST" key to enter speedy adjusting mode.
    2). Press "SET" key, month will flash, then press "ADJUST" key to set month, hold "ADJUST" key to enter speedy adjusting mode.
    3). Press "SET" key, date will flash, then press "ADJUST" key to set date, hold "ADJUST" key to enter speedy adjusting mode.
8. At alarm and calendar setting mode, press "MODE" key to confirm, or no operation in the 2

minutes that follows, the previous setting will be confirmed. And no operation in the 5 minutes that follows, it will return to the time display status.