

WS 1004 – Spoon thermometer

User manual

Measurement of temperature: 0°C ~ +60°C (32°F ~ +140°F)

Resolution: 0.1°C (0,18°F)

Accuracy : ±1°C (1,8°F)

BATTERY: 1 x AG10 battery (INCLUDED)

Operation:

Press the ON/°C/°F button for power switching.

Press the ON/°C/°F button for degrees Celsius or Fahrenheit switching.

The spoon including the metal platelet for temperature measurement correspond to the meet food safety standards. The contact with food is quite safe.

The device may only be dipped into foodstuff/ liquids with the spoon part.

Unit can be washed by mild detergent or water below 60°C (140°F) only. Do not clean it in the dishwasher!