

Instruction manual WS 9120

FEATURES:

Measuring temperature range: 0 ~ 50 °C (32°F - 122°F)

Measuring humidity range: 20% ~ 99%

Resolution: 1°C / 1%

Power: 2 x Micro /AAA (not included)

OPERATION:

Press MODE one time to view calendar

Press MODE one more time to view alarm time

SETTING THE TIME

Press and hold MODE for 3 seconds to enter the time setting mode.

The hour digits are blinking and can be set by pressing UP or DOWN for setting hour.

Press MODE again:

The minute digits are blinking and can be set by pressing UP or DOWN for setting minute.

SETTING THE CALENDAR

Press MODE to the view calendar

Press MODE hold for 3 seconds to enter the calendar setting mode.

The year digits are blinking and can be set by pressing UP or DOWN for setting year.

Press MODE again:

The month digits are blinking and can be set by pressing UP or DOWN for setting month.

Press MODE again:

The day digits are blinking and can be set by pressing UP or DOWN for setting day.

SETTING THE ALARM

Press MODE to view the alarm time

Press MODE hold for 3 seconds to enter the alarm setting mode.

The hour digits are blinking and can be set by pressing UP or DOWN for setting hour.

Press MODE again:

The minute digits are blinking and can be set by pressing UP or DOWN for setting minute.

ALARM ON/OFF

Press UP to turn alarm on/off.

MAX / MIN

Press MAX/MIN to view MAX temperature and humidity record.

Press MAX/MIN again to view MIN temperature and humidity record.

12/24 FORMAT HOUR

At the time mode, Press UP for 3 seconds to switch 12 or 24 format hour time display.

TEMPERATURE DISPLAY FORMAT

Press DOWN to switch °C/°F display.

SNOOZE/LIGHT

In alarm to press SNZ/LIGHT for snooze mode.

Press SNZ/LIGHT to turn on light.