

Kitchen Timer KT-200

Instruction manual

- Powered by battery: 1x AAA, Micro battery (not included)

Count Down Mode

- 1) Count down time is set by the “Minute “ & “ Second” buttons. The Maximum count down timer is 99:59 minutes.
- 2) The count down time will reset to 0:00, if the “Minute “ & “ Second” buttons are depressed simultaneously.
- 3) Once the count down time has been set, the count down timer can be started by pressing the “START/STOP” button. The colon will begin to flash.
- 4) When countdown time is reached, the alarm will sound. Press any of the buttons to switch off the alarm.

Count UP Mode

- 1) The count up timer can only be started when the displayed time has been reset or is at a set time.
- 2) The maximum count up time is 99:59 seconds.
- 3) The count up time can be stopped /started by pressing “START/STOP”.