

Instruction manual

WT 4050 - QUARTZ WALL CLOCK

To start the clock

Insert 1 x Mignon AA LR06 battery into the battery compartment and make sure the battery polarity (+/-) is as indicated.

To set the time

Turn the hand set knob in rear of movement clockwise or counter clockwise until the desired time is obtained on the dial.

Display of hands

Hour hand = axe

Minute hand = saw

General notice

- To clean the outside surfaces use a clean, dry, soft cloth to wipe away fingerprints. Do not use any solvents or abrasive cleaners/ polish.
- Replace the battery if the timekeeping becomes erratic, as this may be an indication of battery exhaustion.
- The electronic devices and exhausted batteries should not be thrown in the normal rubbish tons. Please hand these to your local dealer, a public hazardous waste site or battery collection point.



Consideration of duty according to the battery law

Old batteries do not belong to domestic waste because they could cause damages of health and environment. End-users are committed by law to bring back needed batteries to distributors and other collecting points!