

## **Operating instruction of Geneva 3 XL**

### **1. To start clock**

Open battery cover on the back of clock. Insert two 1.5V AA batteries into battery container in the right direction of “+”, “-” polar, then close battery cover back.

### **2. Time setting**

Turn the time set knob in indicated direction to set correct time.

### **3. Alarm setting**

Turn the alarm set knob in indicated direction to desired alarm time.

### **4. Melody alarm and Bell ring function choice**

You can choose the alarm function by turn the switch on the left side of clock.

### **5. ON/OFF switch**

Turn “ON/OFF” switch to “ON” in the right side of clock, it will alarm with Melody or Bell ring at anytime you set. Turn it to “OFF”, it will not alarm.

### **6. SNOOZE/LIGHT switch**

Around 4 minutes snooze function and light function in the same top switch.

### **7. Note**

Battery is going exhaustion if alarm sound get lower & repeated. Please change battery immediately.