

# Talking Alarm Clock

## Features

- Quartz alarm clock
- Date display
- 4 alarms
- Hourly time announcement
- Stopwatch up to max. 23h 59min 59s
- Volume control (2 steps)
- Blue backlight

## Key instructions

- SET** key: Press once to check the year and talking time. Press for a while to enter into time setting.
- UP** key: Press once to turn on or off the Hourly time announcement function. When it's in setting mode, it uses as an UP-adjusting key.
- MODE** key: Press once to enter into the following modes: Count up → Alarm 1 → Alarm 2 → Alarm 3 → Alarm 4 → Return to normal time
- LIGHT** switch: To turn on or off the backlight
- TALK/LIGHT** key: When LIGHT switch is at ON position, press TALK/LIGHT key to talk time and light up the backlight for 5 seconds, whereas when LIGHT switch is at OFF position, press this key to talk time only.
- VOLUME** switch: To select High or Low volume.

## Time setting

1. Press **SET** key for a while to enter into time setting. The setting digits will flash in the following sequence: Hour → Minute → Year → Month → Day → Hour...
2. Use **UP** key to select the digit. Press **UP** key for a while to speed up the digit up-adjustment.
3. Press **MODE** key to exit the setting mode. The setting is saved automatically and the clock returns to normal time mode.

If there's no any key pressed in 1 minute, the clock will also exit the setting mode and returns to normal time mode. The setting is saved automatically.

## Hourly time announcement

In normal time mode, press **UP** key to turn on or off the hourly time announcement function.

## Count up setting

1. In normal time mode, press **MODE** key once to enter into Count Up mode.
2. Press **UP** key to start or pause counting up.
3. When the clock is counting up, press **SET** key once to change the display of Second digit to “ : ” flashing in the middle. When the clock count up is paused, press **SET** key to reset.

4. In count up mode, press **TALK/LIGHT** key to speak out the current count up time. If **LIGHT** switch is at ON position then backlight will also light up for 5 seconds.

Talking count up time intervals:

*First 10 seconds:* The clock will speak out the current count up time.

*10 second to 1 minute:* The clock will speak out the current count up time every 10 seconds.

*1 minute to 10 minutes:* The clock will speak out the current count up time every 1 minute.

*After 10 minutes:* The clock will speak out the current count up time every 10 minutes.

5. Press **MODE** key to return to normal time mode and speak out the current time. If under normal time mode or alarm mode, the clock will NOT speak out the current count up time as mentioned above. If count up time is not reset or paused, the clock will keep counting up.

#### Alarm time setting

1. In normal time mode press **MODE** key to enter into the following alarm time:  
Count up → Alarm 1 → Alarm 2 → Alarm 3 → Alarm 4 → Return
2. In any alarm mode, press **UP** key to turn on or off the current alarm function.
3. In Alarm 1 mode, press **SET** key for a while to enter into Alarm 1 time setting. The following setting digits will flash in sequence: Alarm 1 hour → Alarm 1 minute
4. Use **UP** key to select the digit. Press **UP** key for a while to speed up the digit up-adjustment.
5. The same setting is applied to Alarm 2, Alarm 3 and Alarm 4.

If there's no any key pressed in 30 seconds, the clock will exit the alarm mode and return to normal time mode and the clock will make two BEEP sounds.



#### **Consideration of duty according to the battery law**

**Old batteries do not belong to domestic waste because they could cause damages of health and environment. End-users are committed by law to bring back needed batteries to distributors and other collecting points!**