



WT 3000 – Radio controlled bathroom clock

Instruction manual

OVERVIEW



LCD SCREEN DISPLAY



FEATURES

- DCF-77 Radio controlled clock with manual setting option
- 12/24 h time display
- Time zone setting (-1/+2 h)
- Date and weekday display (8 languages)
- Indoor temperature display in °C/°F
- Humidity-proof, ideal for bathrooms
- Mounting with 4 suction cups, wall mounting or table standing

GETTING STARTED

1. Twist and lift the back cover.
2. Remove the battery compartment cover.
3. Insert 1x AA battery matching the polarity (+/-).
4. Close the battery cover and the back cover.

AUTOMATICALLY TIME SET

Once the battery is installed, the clock will begin searching for the DCF signal. Within 3-8 minutes the clock will receive the DCF signal and set itself to the exact radio controlled time.

If a signal is not receivable, press the SIGNAL button, the clock will start to search again for the DCF signal.

MANUAL TIME SET

1. Press and hold SIGNAL key for 2 seconds, the clock will stop receive the DCF signal.
2. Press and hold SET key for 2 seconds to enter into time setting mode.
3. The figure to be set will be flashing.
4. Press ▲ or ▼ to change the settings.
5. Press SET key to confirm and go to next setting. The setting order is: 12/24-hr format, Hour, Minute Year, Month, Day, Language.
6. Press SET again to confirm and exit setting.

display language



8 languages display

	ENGLISH	GERMAN	FRENCH	SPANISH	ITALIAN	NETHERLANDS	DENMARK
SUNDAY	SU ^(SUN)	SO ^(SON)	DI ^(DIM)	DO ^(DOM)	DO ^(DOM)	ZO ^(ZON)	SO ^(SON)
MONDAY	MO ^(MON)	MO ^(MON)	LU ^(LUN)	LU ^(LUN)	LU ^(LUN)	MA ^(MAA)	MA ^(MAA)
TUESDAY	TU ^(TUE)	DI ^(DIM)	MA ^(MAA)	MA ^(MAA)	MA ^(MAA)	DI ^(DIM)	TI ^(TID)
WEDNESDAY	WE ^(WED)	MI ^(MIE)	ME ^(MEJ)	MI ^(MIE)	ME ^(MEJ)	WO ^(WON)	ON ^(OND)
THURSDAY	TH ^(THU)	DO ^(DOM)	JE ^(JEU)	JU ^(JUN)	GI ^(GID)	DO ^(DOM)	TO ^(TID)
FRIDAY	FR ^(FRI)	FR ^(FRS)	VE ^(VEJ)	VI ^(VID)	VE ^(VEJ)	VR ^(VRS)	FR ^(FRS)
SATURDAY	SA ^(SAT)	SA ^(SAA)	SA ^(SAA)	SA ^(SAA)	SA ^(SAA)	ZA ^(ZAA)	LO ^(LON)

TIME ZONE SETTING

Within Germany, the time zone setting can be ignored. The time zone will set automatically when the DCF signal is received.

The time zone setting can be used for neighboring countries of Germany, which can receive the DCF-signal from Germany. In London, the time zone to Berlin is shifted by 1 hour, so the time zone in London has to be set to "-1" if the DCF signal can be received from Germany. In Paris, the time zone setting will be ignored because there is no shift to German time.

City & time zone:

		Country	City	ZONE	Time zone setting
1	LON	ENGLAND	London	0	-1
2	DUB	IRELAND	Dublin	0	-1
3	MOW	RUSSIA	Moscow	3	+2
4	ATH	GREECE	Athens	2	+1
5	PAR	FRANCE	Paris	1	00
6	FRA	GERMANY	Frankfurt	1	00
7	CPH	DENMARK	Copenhagen	1	00
8	BCN	SPAIN	Barcelona	1	00
9	AMS	HOLAND	Amsterdam	1	00

TEMPERATURE DISPLAY

The indoor temperature will display within 3-8 minutes automatically after set up.

Press ▼ key to switch between the temperature display formats °C and °F.

POSITIONED METHOD

The bathroom clock can be positioned in 3 ways as desired:

- Pull out the table stand brackets from the rear of the clock, place on table or desk as desired.
- Hang on the wall by hanging hole.
- Hang on the smooth place with suction cap.

RESET

Press RESET key to return to the default settings.

PRECAUTIONS

- This main unit is intended to be used only indoors.
- Do not subject the unit to excessive force or shock.
- Do not expose the unit to extreme temperatures, direct sunlight, dust or humidity.
- Do not immerse in water.

- Avoid contact with any corrosive materials.
- Do not dispose this unit in a fire as it may explode.
- Do not open the inner back case or tamper with any components of this unit.

Batteries safety warnings:

- Please read all instructions carefully before use.
- Use only alkaline batteries, not rechargeable batteries.
- Install batteries correctly by matching the polarities (+/-).
- Always replace a complete set of batteries.
- Never mix used and new batteries.
- Remove exhausted batteries immediately.
- Remove batteries when not in use.
- Do not recharge and do not dispose of batteries in fire as the batteries may explode.
- Ensure batteries are stored away from metal objects as contact may cause a short circuit.
- Avoid exposing batteries to extreme temperature or humidity or direct sunlight.
- Keep all batteries out of reach from children. They are a choking hazard.

Consideration of duty according to the battery law



Old batteries do not belong to domestic waste because they could cause damages of health and environment. You can return used batteries free of charge to your dealer and collection points. As end-user you are committed by law to bring back needed batteries to distributors and other collecting points!

SPECIFICATIONS

Temperature measuring range: -9°C to +50°C (15,8°F to 122°F)
 Resolution: 0.1°C/ 0.1°F
 Accuracy: ± 1°C/ 1°F

Dimensions: Ø 172 x 54mm
 Power requirements: 1 x AA Mignon LR06