

Instruction WT193

FEATURES:

- DCF-77 radio controlled clock
- 12/24-hour time display
- Date display
- Calendar display
- 5 languages selectable display in Day-of-week: German, English, Spanish, Italian and French
- Indoor temperature in °C/°F
- Alarm with snooze function
- Backlight

SETTING UP:

1. Firstly, open the battery cover at the back of the clock.
2. Checking the correct polarization, insert 2 x AAA, LR03, 1.5V batteries into the compartment and replace the cover.
3. When the batteries are inserted, the clock will be automatically scanning for the radio controlled time signal.
4. If after 6 minutes the DCF time has not been received, you can manually set the time. (see chapter manual time setting)
5. If the clock cannot receive the signal at the first time, it will automatically attempt to receive the signal again one hour later.
6. The clock will automatically receive the signal everyday 2.00 am.
7. When the clock is scanning for signal, only the WAVE key is operational.

MANUAL TIME SETTING:

In some cases after inserting the batteries, the clock may not be able to receive the DCF signal. In this situation, the time should be set manually.

1. Press the SET key and then press the UP key to choose the language for the Day of week.
2. Press the SET key again and then press the UP key to choose the time format 12/24h.
3. Press the SET key again and the “second” digits will start flashing. Press the UP key to clear the “second” to 00.
4. Press the SET key again and the “hour” digits will start flashing. Press UP key to adjust the hour.
5. Press the SET key again and the “minute” digits will start flashing. Press the UP key to adjust the minute.
6. Press the SET key again and the “year” digits will start flashing. Press UP key to adjust the year.
7. Press the SET key again and the “month” digits will start flashing. Press the UP key to adjust the month.

8. Press the SET key again and the “date” digits will start flashing. Press the UP key to adjust the date.
9. Press the SET key again to return to normal display.

ALARM SETTING:

1. Press the MODE key.
2. Press and hold the SET key for 3 seconds and the “hour” digits of alarm time will start flashing. Press UP key to adjust the hour.
3. Press the SET key again and the “minute” digits of alarm time will start flashing. Press UP key to adjust the minute.
4. Press the SET key again to return to alarm time display.
5. Press the UP key once to activate alarm on function and twice to inactivate the alarm on function.
6. Press MODE key to return to normal display mode.

FUNCTION KEYS

SNOOZE/LIGHT KEY

- When the alarm beeps, press the SNOOZE/LIGHT key to pause the alarm for 5 minutes and the snooze function can be used repeatedly.

To stop snooze function, just press other keys once.

-Press the SNOOZE/LIGHT key to illuminate the LCD for 3 seconds.

°C/°F KEY

-In normal time display, press the °C/°F key to toggle between Celsius and Fahrenheit temperature readings.

WAVE KEY

-In normal time display, press and hold the WAVE key for 3 seconds to activate the DCF scanning function.

-If the clock is scanning for the DCF signal, press the WAVE key once to inactivate the DCF scanning function.