

Technoline

**WT-465**




## **DIGITAL RADIO ALARM CLOCK**



## **INSTRUCTION MANUAL**

Read this manual carefully to get the best performance from this unit.

## LOCATION OF CONTROL



- |   |                     |
|---|---------------------|
| 1.  / AUTO | 9. PM INDICATOR     |
| 2. MEMORY / TIME SET  | 10. AL1 INDICATOR   |
| 3. TUNING DOWN / MINUTE   | 11. NAP INDICATOR   |
| 4. TUNING UP / HOUR   | 12. FM INDICATOR    |
| 5. VOLUME - / AL2   | 13. AL2 INDICATOR   |
| 6. VOLUME + / AL1   | 14. DIGIT DISPLAY   |
| 7. SNOOZE / DIMMER / SLEEP/ NAP   | 15. FM ANTENNA WIRE |
| 8. SLEEP INDICATOR  | 16. DC INPUT        |

**BOTTOM OF SET:** Battery compartment for 2 x 1.5 volt (LR6, UM-3, AA) batteries. (not included) for temporary time storage.

**GETTING STARTED:** Use the AC/DC adapter to connect the radio alarm clock with a regular household plug.

### SET TIME

1. Press and hold TIME SET for two seconds.
2. Preset 24H shows 24 hour mode.
3. Press Tuning  or  to select 24 or 12 hour mode.
4. Press and hold TIME SET and time digits [0:00] are blinking.
5. Press Tuning  to set the hour and Tuning  to set the minute.
6. Press TIME SET again to confirm setting or the setting will be confirmed automatically if no button is used within 3 seconds.

### LISTEN TO FM RADIO

For better reception, fully extend and adjust the position of the FM antenna wire.

1. Press  / AUTO to turn on FM radio.
  - [FM frequency] is displayed and FM indicator is light up.
2. Press TUNING  or  for two seconds.
  - The FM Tuner tunes to a station with strong reception automatically.

To search for a radio station manually:

Press TUNING  or  repeatedly to tune to a radio station

## STORE FM RADIO STATIONS

You can store up to 20 FM radio stations in preset channel automatically or manually.

### STORE FM RADIO STATIONS AUTOMATICALLY (AUTO SCAN)

1. Press  / AUTO to turn on FM radio.
2. Press  / AUTO and hold for 2 seconds.
  - The received stations are automatically stored to preset numbers.

### STORE FM RADIO STATIONS MANUALLY.

1. Tune to an FM radio station.
2. Press MEMORY to activate the storing mode. The display is blinking.
3. Press TUNING  or  to select the preset number.
  - [P 01 ~ P 20] is preset station numbers.
4. Press MEMORY to select a number for the selected station.

## LISTEN TO A PRESET FM RADIO STATION

In FM mode, press MEMORY to select a preset number.

### Note

The digit display return to clock display if no buttons is pressed for 10 seconds

## SET ALARM TIMER

Make sure that you have set the clock correctly.

You can set two separate alarm timers. For the alarm sound, you can select the FM radio or the buzzer.

1. Press  / AUTO to Clock mode.
2. Press and hold AL1 or AL2 for two seconds and alarm digits [0:00] are blinking.
3. Press Tuning  to set the alarm hour and Tuning  to set the alarm minute.
4. Press TIME SET again to confirm setting or the setting will be confirmed automatically if no button is used within 3 seconds.
5. Press AL1 or AL2 again to select a sound source. FM radio or alarm sound.
  - The options can be selected in following order:  
Alarm off (OFF) > alarm sound (bb) > radio alarm

### Note

The selected radio volume is the alarm volume.

## **SNOOZE ALARM**

When alarm sounds, press SNOOZE to activate the snooze time 9 minutes.

- The AL1 or AL2 indicator keeps blinking.

## **SET SLEEP TIMER**

This radio clock can switch to standby mode automatically after a preset period.

1. Press  / AUTO to radio mode.
2. Press SNOOZE/DIMMER/SLEEP multi-function button repeatedly to select the sleep timer period (in minutes).


To deactivate the sleep timer, press SNOOZE/DIMMER/SLEEP multi-function button repeatedly until back to radio frequency.

## **SET NAP TIMER**

1. Press  / AUTO to clock mode.
2. Press SNOOZE/DIMMER/SLEEP multi-function button repeatedly to select the sleep timer period (in minutes).

To deactivate the nap timer, press SNOOZE/DIMMER/SLEEP multi-function button repeatedly until sleep indicator is off.

Sleep / Nap Timer period circle as follow:



## **ADJUST VOLUME**

While listening, press VOLUME + or - to adjust volume.

## **ADJUST DISPLAY BRIGHTNESS**

Press and hold DIMMER for 2 seconds repeatedly to select a high or low brightness level.

## **BATTERY BACK-UP**

Slide open the battery cover at the back of your clock, then 2 x 1.5 volt (LR6, UM-3, AA) batteries to the battery compartment. Make sure +/- polarity of the battery are facing in the right directions. Then replace the battery cover.

The battery is for back-up only and just helps to save your settings in cases of missing power. There is no display in back-up mode.

### **TROUBLE SHOOTING**

If your clock displays irrelevant time or does not function properly, which maybe caused by electro-static discharge or other interference, unplug the DC jack to disconnect the AC power (and remove the backup battery). The clock will be reset to default settings and you need to set it again.

### **CARE OF YOUR LED ALARM CLOCK**

1. Do not expose the unit to extreme temperature, water or direct sunlight.
2. Avoid contact with any corrosive materials.
3. Do not subject the unit to excessive force, dust or humidity.
4. Do not open the inner back case or tamper with any components of this unit.
5. Do not plug in any other AC/DC adaptor with incorrect specifications or voltage.

### **SPECIFICATIONS**

Power Source	: 100-240V ~50/60Hz,
Tuner Range	: FM 87.5-108.0MHz
Power Consumption	: 5W